

## Welcome

Congratulations on your purchase of the Avido Oceana *Platinum Series* Bluetooth Speaker. Please read this manually carefully before use. Enjoy!

## What's Included

Avido™ Oceana Speaker, Micro-USB Cable, Auxiliary Cable, Manual

## Features

- Bluetooth Speaker with HD Sound
- TF Card (Micro SD) Card Mode
- Auxiliary Connection
- Handsfree Speakerphone
- Voice Prompts for Easy Use

## Specifications

- Bluetooth: V4.0+EDR
- Power: 5W x 2
- Powered by: Built-in 2200mAh Li-Ion Battery
- Unit Size: 180 (W) x 50.5 (D) x 62mm (H)
- Unit Weight: 300g

## Charging The Speaker

- Using the included Micro-USB cable, connect the Micro-USB connector to the speaker, and the standard USB connector to a USB power source, such as a laptop computer or smartphone wall charger. The LED indicator light will illuminate red while charging, and turn off when fully charged.

## LED Indicator Light

- LED Quickly Flashing (Blue)- Bluetooth Mode
- LED Solid (Blue)- Bluetooth Connected
- LED Slowly Flashing (Blue)- Audio is Playing
- LED Solid (Red)- TF Card (Micro SD) Mode
- LED Solid (Red)- The speaker is charging. The LED light will turn off when fully charged.

## Operating Instructions

### Bluetooth

- Power on the Oceana Speaker by pressing and holding the power button on the back of the unit. Pairing mode is automatically enabled.
- On your Bluetooth device find “Avido Speaker” under your Bluetooth settings. (Input “0000” if a password is required). A successful connection will be followed by an audible notification.


\*For help with Bluetooth connections, please consult your devices user's manual.

### Bluetooth Speakerphone Call

- The speakerphone function is enabled when your device is connected via Bluetooth. Press the #4 button (see diagram) to answer a call. Press again to end the call. To decline a call without answering, press and hold the button.

### Micro-SD (TF Card Mode)

- Insert the Micro-SD (TF Card). A voice prompt “TF Card Mode” will be heard when inserted. Press “+” and “-” to skip song tracks. Volume controls and play / pause buttons will work normally.



1. Tap: Next Song  
Press and hold: Volume Up
2. Tap: Previous Song  
Press and hold: Volume Down
3. Tap: Play/ Pause
4. Tap: Answer Phone/ Hang Up and  
Press and hold: Call previous caller
5. LED Indictaor Light

**Avido™**

Platinum Series



# Oceana

## Rechargeable Stereo Wireless HD Speaker

**Instruction Manual**

## Warranty

- Avido warrants this product to be free from defects in materials and workmanship for 1-Year. If your Avido accessory is found to be defective within that time frame, we will promptly repair or replace it. This warranty does not cover accidental damage, wear and tear, or consequential or incidental loss. If you are in need of warranty support, please email [info@avidopower.com](mailto:info@avidopower.com).

## Customer Support

- Please visit our website [www.avidopower.com](http://www.avidopower.com) for additional information and support.

**Avido™**

Avido, LLC  
**1-844-MY-AVIDO**  
[www.AvidoPower.com](http://www.AvidoPower.com)