



## **ZEDA™ Bluetooth Speaker – Instructional Manual**



Thank you and congratulations on your purchase of the Avido™ ZEDA Bluetooth Speaker. To get the most of your new product, please read these instructions before use. Enjoy!


### **Avido ZEDA Features:**

- **Connect-** Connect to the ZEDA speaker using Bluetooth, Micro SD Card (TF Card Mode), USB Flash Drive, and the included 3.5mm auxiliary cable.
- **Watch-** The built in LED lights allow your music to visually come alive. With 9 LED settings to choose from, you will be sure to find your favorite!
- **Listen-** The Avido ZEDA also includes a built-in FM radio!
- **Chat-** Use the Avido ZEDA as a speakerphone to make calls, answer calls, and more.
- **Voice Guidance-** Commands prompts let you know current connection, battery status, and pairing status.

### What's Included:


1. Avido ZEDA Bluetooth Speaker
2. Micro-USB Cable
3. 3.5mm Auxiliary Cable
4. Instruction Manual

### Avido ZEDA Overview:



1. Tap: Mode Change (Bluetooth, FM Radio, Auxiliary Connection, TF Card Mode, USB Input)  
Press and hold: LED light mode selection
2. Tap: Next song  
Press and hold: Volume Up
3. Tap: Previous song  
Press and hold: Volume Down
4. Tap: Play / Pause, Answer Phone / Hang Up
5. Speaker Grill / LED Lights
6. Built-In Microphone

## Avido ZEDA Overview (continued):



- 7. Micro-USB Input (used for charging the speaker)
- 8. USB Flash Drive Input
- 9. ON/OFF Switch
- 10. Auxiliary Input (3.5mm jack). Also used to improve FM Radio reception.
- 11. Micro-SD Card Input (TF Card)
- 12. LED Status Light

### **Avido ZEDA Power On / Off:**

Turning On / Off the Avido ZEDA:

- Slide ON / Off Button to turn on the speaker

### **Power and Mode Selection:**


Upon turning on the ZEDA speaker, the unit will check to see if any external devices have been inserted or attached (Micro SD Card or USB Flash Drive). If so, the unit defaults to this device.

If nothing is detected, the unit will enter “Bluetooth Mode” and a voice prompt will let you know the current mode selection.

### **LED Light Modes:**

The ZEDA speaker has nine LED light choices for your enjoyment. Some of these modes dance to the beat of your music, so be sure to have music playing when changing modes to see the full effect.

To select modes, press and hold the M/\* button. The LED light settings will change with every press and hold.



### **Bluetooth Pairing:**

Power on the Avido ZEDA speaker. Pairing mode is automatically enabled. On your Bluetooth device, find “Avido Speaker” under your Bluetooth settings. (Input 0000 if a passcode is required). A successful Bluetooth connection will be followed by an audible notification.

\*For help with Bluetooth connections, please consult your devices user’s manual.

### **Bluetooth Speakerphone Call:**

The speakerphone function is enabled when your device is connected via Bluetooth. Press the #4 button (Play / Pause, see diagram) to answer a call. Press again to end the call. To decline a call without answering, press and hold the button. For the best conversation experience, turn the speaker so that the mic opening faces the user and keep the talking distance to the speaker within a short distance.

### **FM Radio:**

Tap the mode change button (#1 – see diagram) to change to FM Radio mode. A voice prompt “FM Radio” will be heard. **At this time, please insert your auxiliary cable.** The ZEDA was designed to use the auxiliary cable as an antenna and your FM radio reception will be greatly improved.

To scan FM radio stations (required for first use in new locations), tap the play / pause button. Scanning will take approximately one to two minutes to complete. After this is done, press the “<” and “>” to change stations. To change volume, press and hold the “<” and “>” buttons.

### **Micro- SD (TF Card Mode):**

Insert the Micro-SD (TF Card) into slot #11 (see diagram). A voice prompt “TF Card Mode” will be heard when inserted. Press “<” and “>” to skip song tracks. Volume controls and play / pause buttons will work normally.

### **USB Flash Drive Mode:**

Insert a USB Flash Drive into slot #8 (see diagram). A voice prompt “USB Flash Drive Mode” will be heard when inserted. Press “<” and “>” to skip song tracks. Volume controls and play / pause buttons will work normally.

### **Line-In (Auxiliary) Mode:**

Insert an auxiliary cable into slot #10 (see diagram) and the other end into your device. Press the mode change button (#1 – see diagram) to change to Line-In mode. Volume controls will work normally.

### **Charging the Speaker:**

Using the included Micro-USB cable, connect the Micro-USB connector to the speaker, and the standard USB connector to a USB power source, such

as a laptop computer or smartphone wall charger. The charging will begin and take approximately four hours to complete for a full charge (0-100%).

**Indicator Status:**

- Fast Blinking Blue- Powering On
- Blue / Green- Waiting for Bluetooth Connection
- Solid Blue/ Slow Blinking Blue- Bluetooth Connected
- Solid Green- Radio Mode, Auxiliary Mode, FM Radio, TF Card Mode, USB Flash Drive mode

**Speaker Specifications:**

Output Power: 6W 3W\*2

Frequency: 20-18000HZ(+/-3dB)

S/N:  $\geq 80$ dB

Speaker: 45mm 4 $\Omega$

Input: DC 5V

Size: 19 x 4.8 x 6.8cm

Battery Capacity: 2000mAh

Bluetooth Version: 4.0

**Warranty Information:**

Avido warrants this product to be free from defects in materials and workmanship for 1-Year. If your Avido accessory is found to be defective within that time frame, we will promptly repair or replace it. This warranty does not cover accidental damage, wear and tear, or consequential or incidental loss. If you are in need of warranty support, please email [info@avidopower.com](mailto:info@avidopower.com).

**Customer Support**

Please visit our website [www.avidopower.com](http://www.avidopower.com) for additional information and support.



Avido, LLC  
1-844-MY-AVIDO  
[www.AvidoPower.com](http://www.AvidoPower.com)